

* Minus internal cable routing of lift/carousel (e.g. LL1300-825: 15 m (49' 2.55") – 7 m (22' 11.59") = 8 m (26' 2.96")

Item	Description
1	Shielding
2	Plug, 25-pin
3	Jack, 9-pin
4	Jack, 25-pin

Note:
Using cables for data transfer other than those from the factory can cause data transfer errors and other malfunctions.

Instructions for shielding:
The shielding is always connected to PIN 1 and to the housing of the plug/jack (exception: 9-pin jack).
Internal cable connections are shielded by the control system. Extension cables are not permitted.
It is also necessary to ensure that the earth wire of the lift/carousel and that of the peripheral devices are on the same potential, as otherwise any equalising currents may destroy the interface.

l	Blattkopf Titel, Hinweiszeichen	14.11.07	rep			HÄNEL	Interfaces	Microprocessor Control System Connecting Cable, Periphery to RS232C Connector
k	In OO übertragen	20.04.07	rep					
j	Dateiname	05.12.05	rv	*Datum*	20.04.07			
i	Zusatz max. Kabellänge	25.10.04	es	*Bearb.*	S.Horsinka			
h	9pol. Barcode	08.01.01	rv					
Zust.	*Änderung*	*Datum*	*Name*	*Norm*		*Urpr.*	*Ers.f*	

\infosm\Perip232.en.odt
Seite 1 / 1
RO / LL / MS
Perip232.en.odt